

Omnidirectional Instruction Sheet

- Step 1:** Remove helix nut and washer from the N Female Connector.
- Step 2:** Slide connector through hole in mounting bracket.
- Step 3:** Put washer and helix nut back on the N connector and tighten to 45 in lbs.
- Step 4:** Loosen nuts on the U-bolts so that it is big enough to fit pole diameter.
- Step 5:** Put U-bolts over the pole and tighten nuts to 35 in lbs.



9dBi



12dBi